




# REPLACEMENT PARTS GUIDE


859M Tracked Feller Buncher (PIN: 1T0859MX\_\_ F293917—408745) and (PIN: 1T0859MX\_\_ L343911—408745)





- 


**DIESEL PARTICULATE FILTER (DPF)  
(COMPONENT OF EXHAUST FILTER)**  
[RE563901](#)  
Interval (hrs) - As required.
- 


**DIESEL EXHAUST FLUID (DEF) TANK  
BREATHER**  
[H216169](#)  
Interval (hrs) - 4000.
- 


**FUEL CAP BREATHER ELEMENT**  
[T231314](#)  
Interval (hrs) - 2000.
- 


**DIESEL EXHAUST FLUID (DEF) IN-LINE  
FILTER (IF EQUIPPED)**  
[DZ118548](#)  
Interval (hrs) - 4000.
- 


**DIESEL EXHAUST FLUID (DEF) DOSING UNIT  
FILTER**  
[DZ114640](#)  
Interval (hrs) - 2000.
- 

**CAB FRESH AIR FILTER**  
[AT191102](#)  
Interval (hrs) - 1000.
- 

**CAB RECIRCULATION FILTER**  
[AT307501](#)  
Interval (hrs) - 1000.
- 


**ENGINE ROCKER ARM COVER GASKET**  
[R526607](#)  
Interval (hrs) - 2000.
- 


**DIESEL EXHAUST FLUID (DEF) HEADER  
SUCTION SCREEN AND BAFFLE (S.N.—306262)**  
[AT486844](#)  
Interval (hrs) - 2000.
- 


**DIESEL EXHAUST FLUID (DEF) HEADER  
SUCTION FILTER AND BAFFLE  
(S.N.306263—344119)**  
[AT502964](#)  
Interval (hrs) - 2000.
- 


**HYDRAULIC OIL RETURN FILTER**  
[F061786](#)  
Interval (hrs) - 2000.





- 


**PRIMARY ENGINE AIR FILTER ELEMENT**  
[AH148880](#)  
Interval (hrs) - As required.
- 


**SECONDARY ENGINE AIR FILTER ELEMENT**  
[RE63932](#)  
Interval (hrs) - As required.
- 


**HYDROSTATIC PUMP CASE OIL FILTER  
(IF EQUIPPED)**  
[AT318160](#)  
Interval (hrs) - 2000.
- 


**FINAL FUEL FILTER ELEMENT**  
[DZ112918](#)  
Interval (hrs) - 500.
- 

**HYDRAULIC OIL BREATHER FILTER**  
[F122930](#)  
Interval (hrs) - 2000.
- 

**FUEL PREFILTER ELEMENT (IF EQUIPPED)**  
[R502778](#)  
Interval (hrs) - 500.
- 

**PRIMARY FUEL FILTER ELEMENT**  
[RE539465](#)  
Interval (hrs) - 500.
- 

**AUXILIARY FUEL FILTER ELEMENT  
(IF EQUIPPED)**  
[AT365869](#)  
Interval (hrs) - 500.
- 

**ENGINE OIL FILTER ELEMENT**  
[DZ101884](#)  
Interval (hrs) - 500.
- 

**HYDROSTATIC CHARGE OIL FILTER  
(IF EQUIPPED)**  
[AT412116](#)  
Interval (hrs) - 2000.












CLICK PART NUMBER TO BUY

\*See operator's manual for additional details.

Mar.2022. Release Date.

# OILS AND CAPACITIES INFORMATION

859M Tracked Feller Buncher (PIN: 1T0859MX\_\_ F293917—408745) and (PIN: 1T0859MX\_\_ L343911—408745)

Part Description	Part Number	Qty or capacity	Change Interval In Hours
John Deere Plus-50™ II Engine Oil <sup>3</sup> 	<a href="#">TY26669</a>	31.0 L (8.2 gal)	500
U6 Track Drive Planetary Oil <sup>3</sup> (each) 	<a href="#">TY26372</a>	8.0 L (2.1 gal)	1000
U7 Track Drive Planetary Oil <sup>3</sup> (each) 	<a href="#">TY26372</a>	9.0 L (2.4 gal)	1000
U7L Track Drive Planetary Oil <sup>3</sup> (each) 	<a href="#">TY26372</a>	10.0 L (2.6 gal)	1000
API GL-5 Swing Drive Gear Case Oil <sup>3</sup> (each) 	<a href="#">TY26372</a>	4.5 L (1.2 gal)	1000
Hy-Gard™ Pump Drive Gear Case Oil <sup>3</sup> (if equipped) 	<a href="#">TY6354</a>	6.6 L (1.7 gal)	1000
John Deere Hydrau™ XR Hydraulic Enclosure Door Pump Oil <sup>3</sup> 	<a href="#">TY27318</a>	4.1 L (1.1 gal)	2000
John Deere Hydrau™ Hydraulic Oil <sup>3</sup> 	<a href="#">TY27367</a>	152.0 L (40.2 gal)	2000
Cool-Gard™ II Pre-Mix 	<a href="#">TY26575</a>	46.0 L (12.5 gal)	6000

# OILS AND CAPACITIES INFORMATION

859M Tracked Feller Buncher (PIN: 1T0859MX\_\_ F293917—408745) and (PIN: 1T0859MX\_\_ L343911—408745)

Part Description	Part Number	Qty or capacity	Change Interval In Hours
<b>Fluid Analysis Test Kits<sup>4</sup></b>			
Engine Oil	<a href="#">AT346594</a>	1	250
Hydraulic Oil	<a href="#">AT346594</a>	1	500
Diesel Fuel	<a href="#">TY27329</a>	1	500
Pump Drive Gear Case Oil (if equipped)	<a href="#">AT346594</a>	1	500
Track Drive Planetary Oil	<a href="#">AT346594</a>	2	500
Swing Drive Gear Case Oil <sup>5</sup>	<a href="#">AT346594</a>	2	500
Enclosure Door Pump Oil	<a href="#">AT346594</a>	1	500
Engine Coolant	<a href="#">TY27787</a>	1	500
<p><sup>3</sup> See operator's manual for recommended oil type and oil viscosities based on operating temperatures.</p> <p><sup>4</sup> Based on fluid analysis results, intervals may need to be adjusted for your operating conditions. Consult your local John Deere dealer.</p> <p><sup>5</sup> Machines not equipped with high torque swing option only require one fluid analysis kit.</p>			

*Plus-50 is a trademark of Deere & Company*

*Hydrau is a trademark of Deere & Company*

*Hy-Gard is a trademark of Deere & Company*

*Cool-Gard is a trademark of Deere & Company*

## Service Intervals

As Required	
<input type="checkbox"/> Inspect serpentine belt	<input type="checkbox"/> Lubricate door hinges
<input type="checkbox"/> Replace engine air filter elements	<input type="checkbox"/> Lubricate toolbox door hinges (if equipped)
<input type="checkbox"/> Check and clean cooling system and condenser fins	<input type="checkbox"/> Service exhaust filter
<input type="checkbox"/> Clean and tighten battery terminals	
Every 10 Hours or Daily	
<input type="checkbox"/> Lubricate leveler pivot joints and cylinders (if equipped)	<input type="checkbox"/> Check and drain auxiliary fuel filter and water separator (if equipped)
<input type="checkbox"/> Check fire suppression system (if equipped)	<input type="checkbox"/> Check engine coolant level
<input type="checkbox"/> Check swing drive gear case oil level	<input type="checkbox"/> Check and adjust track sag
<input type="checkbox"/> Check hydraulic oil level	<input type="checkbox"/> Lubricate boom joints and cylinder ends
<input type="checkbox"/> Check engine oil level	<input type="checkbox"/> Lubricate swing drive pinion and bearing
<input type="checkbox"/> Check pump drive gear case oil level (if equipped)	<input type="checkbox"/> Lubricate crank and link (if equipped)
<input type="checkbox"/> Check and drain primary fuel filter and water separator	<input type="checkbox"/> Inspect fire extinguisher
<input type="checkbox"/> Inspect harvesting head chain shot guard (if equipped)	
Initial Service—100 Hours	
<input type="checkbox"/> Check track shoe cap screw torque	
Every 100 Hours	
<input type="checkbox"/> Lubricate swing drive gear case bearing	
Initial Service—250 Hours	
<input type="checkbox"/> Drain and refill swing drive gear case oil	<input type="checkbox"/> Drain and refill pump drive gear case oil (if equipped)
<input type="checkbox"/> Drain and refill track drive planetary oil	<input type="checkbox"/> Check lower roller mounting cap screw torque
Every 250 Hours	
<input type="checkbox"/> Check rear window alternative exit latches and retainer knobs	<input type="checkbox"/> Check track drive planetary oil level
<input type="checkbox"/> Check skylight latch tension	<input type="checkbox"/> Check track shoe cap screw torque
<input type="checkbox"/> Take engine oil sample	
Every 500 Hours	
<input type="checkbox"/> Replace fuel prefilter (if equipped)	<input type="checkbox"/> Take diesel fuel sample
<input type="checkbox"/> Replace primary fuel filter and water separator	<input type="checkbox"/> Take hydraulic oil sample
<input type="checkbox"/> Replace final fuel filter	<input type="checkbox"/> Take pump drive gear case oil sample (if equipped)
<input type="checkbox"/> Replace auxiliary fuel filter and water separator (if equipped)	<input type="checkbox"/> Take track drive planetary oil sample
<input type="checkbox"/> Drain and refill engine oil and replace filter	<input type="checkbox"/> Take swing drive gear case oil sample
<input type="checkbox"/> Check hybrid battery electrolyte level (if equipped)	<input type="checkbox"/> Check enclosure door pump oil level
<input type="checkbox"/> Check air intake hoses	<input type="checkbox"/> Take engine coolant sample
<input type="checkbox"/> Drain water and sediment from fuel tank	<input type="checkbox"/> Take enclosure door pump oil sample

## Service Intervals

Every 1000 Hours	
<input type="checkbox"/> Drain and refill swing drive gear case oil	<input type="checkbox"/> Drain and refill track drive planetary oil
<input type="checkbox"/> Check coolant condition	<input type="checkbox"/> Drain and refill pump drive gear case oil (if equipped)
<input type="checkbox"/> Check cab fresh air and cab recirculation air filters	
Every 2000 Hours	
<input type="checkbox"/> Drain and refill hydraulic oil	<input type="checkbox"/> Drain and refill enclosure door pump oil
<input type="checkbox"/> Replace hydraulic oil return filters	<input type="checkbox"/> Replace diesel exhaust fluid (DEF) dosing unit filter
<input type="checkbox"/> Replace hydraulic oil breather filter	<input type="checkbox"/> Check and adjust engine valve lash
<input type="checkbox"/> Replace hydrostatic charge oil filter (if equipped)	<input type="checkbox"/> Check open crankcase vent (OCV)
<input type="checkbox"/> Replace hydrostatic pump case oil filter (if equipped)	<input type="checkbox"/> Replace fuel cap breather element
<input type="checkbox"/> Clean diesel exhaust fluid (DEF) tank (S.N. —306262)	<input type="checkbox"/> Replace diesel exhaust fluid (DEF) tank fill screen (S.N. —306262)
<input type="checkbox"/> Clean diesel exhaust fluid (DEF) tank (S.N. 306263—344119)	<input type="checkbox"/> Replace diesel exhaust fluid (DEF) header suction screen and baffle (S.N. —306262)
<input type="checkbox"/> Replace diesel exhaust fluid (DEF) header suction filter and baffle (S.N. 306263—344119)	
Every 4000 Hours	
<input type="checkbox"/> Replace diesel exhaust fluid (DEF) tank breather filter	
Every 6000 Hours	
<input type="checkbox"/> Drain and refill engine coolant	<input type="checkbox"/> Replace diesel exhaust fluid (DEF) in-line filter (if equipped)