

# REPLACEMENT PARTS GUIDE

## 316GR Skid Steer Loader (PIN: 1T0316G\_\_G298752-)



### CAB RECIRCULATION AIR FILTER ELEMENT (IF EQUIPPED)

[AT359416](#)

Interval (hrs) - As Required.

### CAB FRESH AIR FILTER ELEMENT (IF EQUIPPED)

[AT441536](#)

Interval (hrs) - As Required.

### DUST UNLOADER VALVE

[M89679](#)

Interval (hrs) - As Required.

### HYDRAULIC OIL RESERVOIR BREATHER

[AT443309](#)

Interval (hrs) - 1000.

### HYDRAULIC OIL FILTER ELEMENT

[AT314164](#)

Interval (hrs) - 1000.

### ENGINE ROCKER ARM COVER GASKET

[MIU800399](#)

Interval (hrs) - 1500.

### ENGINE AIR FILTER ELEMENT - PRIMARY

[AT338105](#)

Interval (hrs) - As Required.

### ENGINE AIR FILTER ELEMENT - SECONDARY

[AT336803](#)

Interval (hrs) - As Required.

### FUEL TANK BREATHER

[H216169](#)

Interval (hrs) - 1000.

### ENGINE OIL FILTER ELEMENT

[MIU800650](#)

Interval (hrs) - 500.

### FINAL FUEL FILTER ELEMENT

[MIU801090](#)

Interval (hrs) - 500.

### PRIMARY FUEL FILTER AND WATER SEPARATOR

[MIU801025](#)

Interval (hrs) - 500.



# OIL AND CAPACITIES INFORMATION

## 316GR Skid Steer Loader (PIN: 1T0316G\_\_\_G298752- )

Part Description	Qty or capacity	Change Interval In Hours
John Deere Plus-50™ II Engine Oil <sup>2</sup>	7.5 L (2.0 gal)	500
John Deere Hydrau™ Hydraulic and Hydrostatic System Oil <sup>2</sup>	22.7 L (6.0 gal)	1000
John Deere Hy-Gard™ Chain Case Oil <sup>2</sup> (per side)	14.3 L (3.8 gal)	1000
John Deere Cool-Gard™ II Pre-Mix (316GR and 318G only)	12.0 L (3.2 gal)	6000
Fluid Analysis Kits <sup>3</sup>		
Diesel Engine Oil	1	500
Hydraulic Oil	1	500
Hydrostatic oil	1	500
Diesel Fuel	1	500
Engine Coolant	1	500
<sup>2</sup> For recommended oil types and oil viscosities based on operating temperatures, see operator's manual. <sup>3</sup> Based on fluid analysis results, intervals may need to be adjusted for operating conditions. Consult an authorized John Deere dealer.		

Plus-50 is a trademark of Deere & Company  
 Hy-Gard is a trademark of Deere & Company  
 Hydrau is a trademark of Deere & Company  
 Cool-Gard is a trademark of Deere & Company

## Service Interval

As Required	
<input type="checkbox"/> Check and clean cooling package	<input type="checkbox"/> Check fuel tank breather
<input type="checkbox"/> Check tire pressure	<input type="checkbox"/> Replace primary and secondary engine air filter elements
<input type="checkbox"/> Check wheel lug nut torque	<input type="checkbox"/> Check and drain primary fuel filter and water separator
<input type="checkbox"/> Replace cab fresh air filter element (if equipped)	<input type="checkbox"/> Check accessory drive belt
<input type="checkbox"/> Replace cab recirculation air filter element (if equipped)	<input type="checkbox"/> Lubricate steering centering mechanism (if equipped)
Every 10 Hours or Daily	
<input type="checkbox"/> Check engine oil level	<input type="checkbox"/> Check hydraulic system oil level
<input type="checkbox"/> Check coolant level	<input type="checkbox"/> Lubricate boom linkage, cylinder, and Quik-Tatch™ pivot points
Every 50 Hours	
<input type="checkbox"/> Check and clean dust unloader valve	<input type="checkbox"/> Lubricate Quik-Tatch™ engagement pins
Every 250 Hours	
<input type="checkbox"/> Take engine oil sample	
Every 500 Hours	
<input type="checkbox"/> Drain and refill engine oil and replace filter	<input type="checkbox"/> Lubricate foot pedals (if equipped)
<input type="checkbox"/> Replace primary fuel filter and water separator	<input type="checkbox"/> Lubricate steering linkage (if equipped)
<input type="checkbox"/> Replace final fuel filter	<input type="checkbox"/> Take engine coolant sample
<input type="checkbox"/> Drain water and sediment from fuel tank	<input type="checkbox"/> Take hydraulic oil sample
<input type="checkbox"/> Check chain case oil level	<input type="checkbox"/> Take diesel fuel sample
Every 1000 Hours	
<input type="checkbox"/> Drain and refill hydraulic oil and replace filter	<input type="checkbox"/> Check coolant condition
<input type="checkbox"/> Replace hydraulic oil reservoir breather	<input type="checkbox"/> Drain and refill chain case oil
<input type="checkbox"/> Replace fuel tank breather	
Every 1500 Hours	
<input type="checkbox"/> Check and adjust engine valve lash	
Every 6000 Hours	
<input type="checkbox"/> Drain, flush, and refill cooling system	